


# 1988 LTD PARTS DIAGRAM

Rear Wheel/Chain

F2240-0056

**FRONT**



# 1988 LTD PARTS LIST

## Rear Wheel/Chain

ITEM NAME	PART NUMBER	QUANTITY
SPROCKET-ASSY,REAR HUB,50T (Ref # 21053)	21053-1007	1
DRUM-ASSY,REAR BRAKE (Ref # 41034)	41034-1159	1
PANEL-ASSY-BRAKE,RR (Ref # 41035)	41035-1089	1
SHOE-BRAKE (Ref # 41048)	41048-020	2
CAM-BRAKE (Ref # 41050)	41050-1001	1
LEVER-BRAKE CAM (Ref # 41053)	41053-1001	1
AXLE,RR (Ref # 41068)	41068-1083	1
INDICATOR,BRAKE SHOE (Ref # 41085)	41085-004	1
COUPLING-ASSY,REAR HUB (Ref # 42033)	42033-1044	1
SLEEVE,RR HUB COUPLING (Ref # 42036)	42036-1002	1
RING,REAR HUB SPROCKET,OUTER (Ref # 43058)	43058-1016	1
RING,REAR HUB SPROCKET,INNER (Ref # 43058A)	43058-1024	1
BELT,DRIVE,121T (Ref # 59011)	59011-1002	1
BOLT,HUB SPROCKET,10X55 (Ref # 92001)	92003-156	4
SCREW,5X10 (Ref # 92009)	92009-1167	8
NUT,16MM (Ref # 92015)	92015-055	1
WASHER,SPROCKET LOCK (Ref # 92022)	92088-005	2
COLLAR,REAR AXLE,LH,L=23.5 (Ref # 92027)	92027-1368	1
RING-SNAP,47MM (Ref # 92033)	92033-1042	1
RING-SNAP,52MM (Ref # 92033A)	92033-1043	1
BEARING-BALL,#6303NS (Ref # 92045)	92045-034	1
SEAL-OIL,TWC35527 (Ref # 92049)	92052-006	1
DAMPER,SHOCK,RR HUB (Ref # 92075)	92075-1008	1
SPRING,BRAKE SHOE (Ref # 92081)	42020-004	2
SEAL,BRAKE CAM (Ref # 92093)	41051-003	1
COLLAR (Ref # 92143)	92027-1487	1
COLLAR,17.2X25X61 (Ref # 92143A)	92143-1101	1
BOLT-SMALL,8X28 (Ref # 114)	114G0828	1
NUT-HEX-FINE,10MM (Ref # 314)	314B1000	4

# 1988 LTD PARTS LIST

## Rear Wheel/Chain

ITEM NAME	PART NUMBER	QUANTITY
WASHER-PLAIN-SMALL,8MM (Ref # 410)	410B0800	1
PIN-COTTER,4.0X35 (Ref # 550)	550D4035	1
BEARING-BALL,#6205C3 (Ref # 601)	601B6205	1
BEARING-BALL,#6303C3 (Ref # 601A)	601B6303	1
O RING,60MM (Ref # 671)	671B2560	1