


2000 Vulcan 1500 Nomad PARTS DIAGRAM

Turn Signals

F2730



2000 Vulcan 1500 Nomad PARTS LIST

Turn Signals

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED-SMALL (Ref # 132)	132E0612	2
BOLT-FLANGED-SMALL (Ref # 132A)	132J0614	2
GASKET,SIGNAL LAMP (Ref # 11009)	11009-1413	4
CAP,SIGNAL LAMP (Ref # 11012)	11012-1367	2
COVER (Ref # 14090)	14090-1691	1
LAMP-ASSY-SIGNAL,RR,LH (Ref # 23037)	23037-1321	1
LAMP-ASSY-SIGNAL,RR,RH (Ref # 23037A)	23037-1322	1
LAMP-ASSY-SIGNAL,FR,LH (Ref # 23037D)	23037-1377	1
LAMP-ASSY-SIGNAL,FR,RH (Ref # 23037E)	23037-1378	1
LENS-SIGNAL LAMP (Ref # 23048)	23048-1066	4
BRACKET-SIGNAL LAMP,RR (Ref # 23051)	23051-1230	1
WASHER,PLAIN,4MM (Ref # 23058)	23058-002	8
STAY-COMP,SIGNAL LAMP (Ref # 39137)	39137-1071	1
BOLT,6X22 (Ref # 92002)	92002-1262	2
SCREW,TAPPING,4X25 (Ref # 92009)	92009-1637	8
NUT,FLANGED,10MM (Ref # 92015)	92015-1428	4
COLLAR,6.8X10X12 (Ref # 92027)	92027-162	2
BULB,12V 32CP(23W) (Ref # 92069)	92069-055	2
BULB,12V 32/3CP(23/8W) (Ref # 92069A)	92069-060	2
DAMPER (Ref # 92160)	92160-1162	2