


2004 Vulcan 1500 Nomad Fi PARTS DIAGRAM

Turn Signals

F2730



2004 Vulcan 1500 Nomad Fi PARTS LIST

Turn Signals

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED-SMALL (Ref # 132)	132E0612	2
BOLT-FLANGED-SMALL (Ref # 132A)	132J0612	2
GASKET,SIGNAL LAMP (Ref # 11009)	11009-1413	4
CAP,SIGNAL LAMP (Ref # 11012)	11012-1367	2
COVER (Ref # 14090)	14090-1691	1
LAMP-ASSY-SIGNAL,RR,LH (Ref # 23037)	23037-1388	1
LAMP-ASSY-SIGNAL,RR,RH (Ref # 23037A)	23037-1389	1
LAMP-ASSY-SIGNAL,FR,LH (Ref # 23037B)	23037-1426	1
LAMP-ASSY-SIGNAL,FR,RH (Ref # 23037C)	23037-1427	1
LENS-SIGNAL LAMP (Ref # 23048)	23048-1065	2
LENS-SIGNAL LAMP (Ref # 23048A)	23048-1066	2
BRACKET-SIGNAL LAMP,RR (Ref # 23051)	23051-1230	1
WASHER,PLAIN,4MM (Ref # 23058)	23058-002	8
STAY-COMP,SIGNAL LAMP (Ref # 39137)	39137-1071	1
BOLT,6X22 (Ref # 92002)	92002-1262	2
SCREW,TAPPING,4X25 (Ref # 92009)	92009-1637	8
NUT,10MM (Ref # 92015)	92015-1356	4
COLLAR,6.8X10X12 (Ref # 92027)	92027-162	2
BULB,12V 21/5W (Ref # 92069)	92069-063	2
BULB,12V 21W (Ref # 92069A)		2
DAMPER (Ref # 92160)	92160-1162	2