


2006 STX-15F PARTS DIAGRAM

Seat

F3146



2006 STX-15F PARTS LIST

Seat

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,SEAT (Ref # 11049)	11049-3735	1
BRACKET (Ref # 11053)	11053-3785	1
PLATE,FRONT SEAT HOOK,OUTER (Ref # 13270)	13270-3910	1
HOOK,FRONT SEAT LOCK (Ref # 27012)	27012-3858	1
LOCK-ASSY,SEAT,F.BLACK (Ref # 27016)	27016-3744-6Z	1
LOCK-ASSY,FRONT SEAT (Ref # 27016A)	27016-3747	1
SEAT-ASSY,FR,BLACK (Ref # 53066)	53066-3709-MA	1
SEAT-ASSY,RR,L.GREEN (Ref # 53066D)	53066-3710-12D	1
SEAT-ASSY,RR,F.SILVER (Ref # 53066E)	53066-3710-12E	1
NUT,FLANGED,8MM (Ref # 92015)	92015-3709	3
NUT,6MM (Ref # 92015A)	92015-3767	2
BOLT,6X18 (Ref # 92150)	92150-3729	2
WASHER,6.5X20X1.5 (Ref # 92200)	92200-3715	2
WASHER,8.5X25X1.5 (Ref # 92200A)	92200-3717	3
WASHER,8.5X18X3 (Ref # 92200B)	92200-3761	2