


2005 STX-15F PARTS DIAGRAM

Fuel Tank



2005 STX-15F PARTS LIST

Fuel Tank

ITEM NAME	PART NUMBER	QUANTITY
GASKET,TANK CAP (Ref # 11009)	11009-3020	1
GASKET (Ref # 11061)	11061-3701	1
PIPE (Ref # 32152)	32152-3705	1
VALVE-RELIEF (Ref # 49057)	49057-3707	1
TANK-FUEL (Ref # 51004)	51004-3739	1
CAP-TANK,FUEL (Ref # 51049)	51049-3725	1
FILLER,FUEL TANK (Ref # 59231)	59231-3716	1
SCREW,TAPPING,4X16 (Ref # 92009)	92009-3849	4
WASHER (Ref # 92022)	92022-563	4
CLAMP (Ref # 92037)	92037-3009	1
CLAMP (Ref # 92037A)	92037-3738	1
CHAIN,COVER,L=100 (Ref # 92057)	92057-3704	1
BAND (Ref # 92072)	92072-3845	2
BAND (Ref # 92072A)	92072-3850	2
BAND,L=99 (Ref # 92072B)	92072-3871	8
TUBE,5.8X10.8X1000 (Ref # 92191)	92191-3736	1
TUBE,5.8X10.8X100 (Ref # 92191A)	92191-3828	1
TUBE,FUEL TANK - FILLER (Ref # 92191B)	92191-3903	1
TUBE,CORRUGATED,L=120 (Ref # 92192)	92192-3749	1
TUBE,CORRUGATED,L=700 (Ref # 92192A)	92192-3750	1