


# 2008 Ultra LX PARTS DIAGRAM

Fuel Pump

E1520



## 2008 Ultra LX PARTS LIST

### Fuel Pump

ITEM NAME	PART NUMBER	QUANTITY
HOLDER (Ref # 13280)	13280-3735	1
PUMP-FUEL (Ref # 49040)	49040-3719	1
TUBE-ASSY,FUEL (Ref # 51044)	51044-3705	1
CLAMP (Ref # 92170)	92170-3760	1
CLAMP (Ref # 92171)	92171-3716	1