


1996 Eliminator 600 PARTS DIAGRAM

Air Cleaner

E1130



1996 Eliminator 600 PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
FILTER-ASSY-AIR,FR (Ref # 11010)	11010-1544	1
FILTER-ASSY-AIR,RR (Ref # 11010A)	11010-1556	1
FILTER-ASSY-AIR,FR (Ref # 11010B)	11010-1558	1
CAP,AIR FILTER ELEMENT (Ref # 11012)	11012-1503	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-1139	1
HOLDER,AIR FILTER ELEMENT (Ref # 13091)	13091-1870	1
PLATE,IGNITION COIL (Ref # 13169)	13169-1664	1
COVER,AIR INTAKE (Ref # 14024)	14024-1215	1
DUCT,CARBURETOR (Ref # 14073)	14073-1211	4
DUCT,LH (Ref # 14073A)	14073-1249	1
DUCT,RH (Ref # 14073B)	14073-1250	1
DUCT,AIR INTAKE (Ref # 14073C)	14073-1251	1
VALVE,AIR SWITCH (Ref # 16126)	16126-1005	1
COVER-SIDE,AIR FILTER,LH (Ref # 36001)	36001-1326	1
COVER-SIDE,AIR FILTER,RH (Ref # 36001A)	36001-1327	1
FITTING,TUBE,T-TYPE (Ref # 92005)	92005-1017	1
CLAMP,TUBE (Ref # 92037)	92037-072	2
CLAMP,TUBE (Ref # 92037A)	92037-1076	1
CLAMP (Ref # 92037B)	92037-1554	1
CLAMP (Ref # 92037C)	92037-1730	1
CLAMP,TUBE (Ref # 92037D)	92037-213	4
TUBE,4X9X220 (Ref # 92059)	92059-1040	1
TUBE,4X9X80 (Ref # 92059A)	92059-1365	1
TUBE,BREATHER (Ref # 92059B)	92059-1545	1
TUBE,AIR SWITCH VALVE,LH (Ref # 92059C)	92059-1674	1
TUBE,AIR SWITCH VALVE,RH (Ref # 92059D)	92059-1675	1
TUBE,AIR SWITCH-AIR FILTER (Ref # 92059E)	92059-1684	1
TUBE,4X9X260 (Ref # 92059F)	92059-1712	1
GROMMET,AIR FILTER (Ref # 92071)	92071-1013	1

1996 Eliminator 600 PARTS LIST

Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
GROMMET,AIR FILTER (Ref # 92071A)	92071-1114	1
DAMPER (Ref # 92075)	92075-1470	6
SPRING,COIL (Ref # 92081)	92081-1177	1
SEAL,AIR FILTER CAP (Ref # 92093)	92093-1212	1
SPRING,AIR FILTER DUCT (Ref # 92144)	92144-1771	4
BOLT-FLANGED,6X10 (Ref # 130)	130B0610	1
SCREW-PAN-WP-CROS (Ref # 224)	224B0612	3
TUBE-RUBBER (Ref # 702)	702A05200	1