


# 1988 Voyager PARTS DIAGRAM

Engine Cover(s)



# 1988 Voyager PARTS LIST

## Engine Cover(s)

ITEM NAME	PART NUMBER	QUANTITY
GASKET,ENGINE COVER,LH (Ref # 11009)	11009-1090	1
GASKET,MISSION COVER (Ref # 11009A)	11009-1091	1
GASKET,CLUTCH COVER (Ref # 11009B)	11009-1092	1
GASKET,BEARING CAP (Ref # 11009C)	11009-1159	1
GASKET,GENERATOR COVER (Ref # 11009D)	11009-1269	1
GASKET,OIL INSPECTION COVER (Ref # 11009E)	11009-1270	1
CAP,TIMING SPROCKET (Ref # 11012)	11012-1060	1
SWITCH-COMP,NEUTRAL (Ref # 13151)	13151-1013	1
PLATE,BAFFLE,BREATHER (Ref # 13169)	13169-1131	1
CAP-BEARING,OUTLET SHAFT (Ref # 14022)	14022-1005	1
COVER,TRANSMISSION,SILVER #10 (Ref # 14024)	14025-1617	1
COVER,RELEASE (Ref # 14024A)	14025-1618	1
COVER,LH,GENERATOR (Ref # 14024B)	14025-1703	1
COVER,OIL INSPECTION (Ref # 14024C)	14025-1704	1
COVER,CLUTCH COVER (Ref # 14024D)	14025-1814	1
COVER-CLUTCH (Ref # 14032)	14032-1111	1
COVER-COMP,GENERATOR (Ref # 14041)	14041-1024	1
CAP-OIL FILLER (Ref # 16115)	16115-1009	1
GAUGE,OIL LEVEL (Ref # 52005)	52005-1017	1
BOLT,FLANGED,6X28 (Ref # 92001)	92003-202	4
BOLT,6X35 (Ref # 92002)	92002-1282	24
BOLT,6X50 (Ref # 92002A)	92002-1283	4
NUT,LOCK,5MM (Ref # 92015)	92018-004	1
WASHER,5.5X20X1.2 (Ref # 92022)	92022-104	1
CLAMP,CABLE (Ref # 92037)	92037-1152	1
BEARING-NEEDLE,7E-HK1412 (Ref # 92046)	92046-037	1
SEAL-OIL,TC14244.8 (Ref # 92049)	92049-1037	1
SEAL-OIL,TC35527 (Ref # 92049A)	92049-1038	1
SEAL-OIL,TB13225.5 (Ref # 92049B)	92051-005	1

# 1988 Voyager PARTS LIST

## Engine Cover(s)

ITEM NAME	PART NUMBER	QUANTITY
RING-O,31.5X2.6 (Ref # 92055)	92055-049	1
GROMMET (Ref # 92071)	92071-1051	1
GROMMET,CLUTCH COVER (Ref # 92071A)	92071-1108	1
DAMPER,CLUTCH COVER (Ref # 92075)	92075-1594	1
BOLT-SOCKET (Ref # 120)	120Z0614	2
BOLT-SOCKET (Ref # 120A)	120Z0616	1
BOLT-SOCKET (Ref # 120B)	120Z0635	9
BOLT-SOCKET (Ref # 120C)	120Z0645	4
SCREW-CSK-RD-CROS (Ref # 222)	222E0510	2
SCREW-PAN-WS-CROS (Ref # 223)	223B0612	3
O RING,45MM (Ref # 670)	670B3045	1