


# 2008 Mule 3010 Trans4x4 Diesel PARTS DIAGRAM

Shift Lever(s)

F2134



## 2008 Mule 3010 Trans4x4 Diesel PARTS LIST

Shift Lever(s)

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,SHIFT CONTROL (Ref # 11052)	11052-1263	1
LEVER,DIFF MODE CONTROL (Ref # 13168)	13168-1428	2
LEVER,SHIFT (Ref # 13168A)	13168-1719	1
ARM (Ref # 21083)	21083-1151	1
ARM (Ref # 21083A)	21083-1152	1
ARM (Ref # 21083B)	21083-1155	1
ARM (Ref # 21083C)	21083-1162	1
ROD-TIE (Ref # 39111)	39111-1169	1
GRIP,SHIFT LEVER (Ref # 46075)	46075-0054	1
GRIP,UPP (Ref # 46075A)	46075-1085	2
GRIP,LWR (Ref # 46075B)	46075-1086	2
GUARD,FRONT DIFF CASE (Ref # 55020)	55020-0171	1
NUT,LOCK,FLANGED,6MM (Ref # 92015)	92015-1675	5
WASHER,10.5X26X2.3 (Ref # 92022)	92022-044	2
COLLAR (Ref # 92027)	92027-1987	2
BUSHING (Ref # 92028)	92028-1507	10
PIN,10X34 (Ref # 92043)	92043-1069	2
SPRING (Ref # 92081)	92081-1714	2
SPRING (Ref # 92081A)	92081-1847	1
SPRING (Ref # 92144)	92144-1510	2
SPRING (Ref # 92145)	92145-0073	1
SPRING (Ref # 92145A)	92145-1326	1
BOLT,6MM (Ref # 92151)	92151-1746	2
BOLT,6MM (Ref # 92151A)	92151-1747	1
DAMPER (Ref # 92160)	92160-3754	2
NUT,LOCK,10MM (Ref # 92210)	92210-1204	2
BOLT-FLANGED,6X14 (Ref # 130)	130C0614	4
BOLT-FLANGED,10X16 (Ref # 130A)	130G1016	4
SCREW-PAN-CROSS,5X14 (Ref # 220)	220F0514	2

## 2008 Mule 3010 Trans4x4 Diesel PARTS LIST

Shift Lever(s)

ITEM NAME	PART NUMBER	QUANTITY
NUT-HEX-FINE (Ref # 315)	315J1000	1
CIRCLIP-TYPE-E,8MM (Ref # 482)	482L8000	4
PIN-SNAP,10MM (Ref # 554)	554A1000	2