


2004 Ninja® ZX™-10R PARTS DIAGRAM

Turn Signals



2004 Ninja® ZX™-10R PARTS LIST

Turn Signals

ITEM NAME	PART NUMBER	QUANTITY
SCREW-PAN-WP-CROS,4X8 (Ref # 224)	224C0408	2
GASKET,SIGNAL LAMP (Ref # 11009)	11009-1402	4
LAMP-ASSY-SIGNAL,FR (Ref # 23037)	23037-0040	2
LAMP-SIGNAL,RR,LH (Ref # 23040)	23040-0027	1
LAMP-SIGNAL,RR (Ref # 23040A)	23040-0028	1
LENS-SIGNAL LAMP (Ref # 23048)	23048-1054	2
LENS-SIGNAL LAMP (Ref # 23048A)	23048-1055	2
BRACKET-SIGNAL LAMP,FR (Ref # 23051)	23051-1207	2
BRACKET-SIGNAL LAMP (Ref # 23051A)	23051-1251	2
SCREW,TAPPING,3X16 (Ref # 92009)	92009-1115	8
SCREW,TAPPING,4X20 (Ref # 92009A)	92009-1304	4
NUT,FLANGED,6MM (Ref # 92015)	92015-1367	4
WASHER,SIGNAL LAMP (Ref # 92022)	92022-1672	2
BULB,12V 21W (Ref # 92069)		4
DAMPER,SIGNAL LAMP (Ref # 92075)	92075-1698	2
WASHER,SIGNAL LAMP (Ref # 92200)	92200-1016	2
WASHER (Ref # 92200A)	92200-1021	2
WASHER,SIGNAL LAMP (Ref # 92200B)	92200-1520	2