


2005 Ninja® ZX™-10R PARTS DIAGRAM

Rear Wheel/Chain

F2240



2005 Ninja® ZX™-10R PARTS LIST

Rear Wheel/Chain

ITEM NAME	PART NUMBER	QUANTITY
PIN-COTTER,4.0X35 (Ref # 550)	550D4035	1
BEARING-BALL,6204UUC3 (Ref # 601)	601B6204UU	2
BEARING-BALL (Ref # 601A)	601B6205UU	1
O RING,60MM (Ref # 671)	671B2560	1
AXLE,RR (Ref # 41068)	41068-0012	1
WHEEL-ASSY,RR,BLACK (Ref # 41073)	41073-0013-R2	1
COUPLING-ASSY,RR HUB (Ref # 42033)	42033-0003	1
SLEEVE,RR HUB,L=23 (Ref # 42036)	42036-1251	1
SPROCKET-HUB,39T (Ref # 42041)	42041-0005	1
NUT,CASTLE,18MM (Ref # 42045)	42045-018	1
STUD,10X19 (Ref # 92004)	92004-1275	6
NUT,FLANGED,10MM (Ref # 92015)	92015-1335	6
RING-SNAP,52MM (Ref # 92033)	92033-1043	1
SEAL-OIL,BJN28475 (Ref # 92049)	92049-1056	1
SEAL-OIL,TWC35527 (Ref # 92052)	92052-006	1
CHAIN,DRIVE,RK525MFOX110L (Ref # 92057)	92057-0087	1
JOINT-CHAIN,DRIVE (Ref # 92058)	92058-0005	1
COLLAR,RR HUB,L=144.5 (Ref # 92152)	92152-0088	1
COLLAR,RR AXLE,RH,L=17 (Ref # 92152A)	92152-0105	1
COLLAR,RR AXLE,LH,L=18 (Ref # 92152B)	92152-0206	1
DAMPER,SHOCK,RR HUB (Ref # 92161)	92161-0058	4
WASHER,19X32X2.6 (Ref # 92200)	92200-1489	1