


2007 Ninja® ZX™-10R PARTS DIAGRAM

Transmission



2007 Ninja® ZX™-10R PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
BALL-STEEL,5/32" (Ref # 600)	600A0500	3
SHAFT-TRANSMISSION INPUT,15T (Ref # 13127)	13127-0027	1
SHAFT-TRANSMISSION OUTPUT,13T (Ref # 13128)	13128-0019	1
SPROCKET-OUTPUT,17T,#525 (Ref # 13144)	13144-0004	1
GEAR,INPUT 5TH,21T (Ref # 13262)	13262-0135	1
GEAR,INPUT 6TH,23T (Ref # 13262A)	13262-0136	1
GEAR,OUTPUT 4TH,32T (Ref # 13262B)	13262-0166	1
GEAR,OUTPUT LOW,38T (Ref # 13262C)	13262-0170	1
GEAR,OUTPUT 6TH,30T (Ref # 13262D)	13262-0171	1
GEAR,INPUT 3RD&4TH,19T&21T (Ref # 13262E)	13262-0288	1
GEAR,OUTPUT 3RD,33T (Ref # 13262F)	13262-0291	1
GEAR,OUTPUT 5TH,29T (Ref # 13262G)	13262-0293	1
GEAR,OUTPUT 2ND,39T (Ref # 13262H)	13262-0349	1
GEAR,INPUT 2ND,19T (Ref # 13262I)	13262-0350	1
NUT,20MM (Ref # 92015)	92015-1963	1
RING-SNAP,20X25.5X1.2 (Ref # 92033)	92033-025	2
RING-SNAP,25.9X30.6X1.2 (Ref # 92033A)	92033-1037	5
RING-SNAP,T=1.5 (Ref # 92033B)	92033-1249	1
BEARING-BALL,DAC2557NSSH (Ref # 92045)	92045-0003	1
BEARING-BALL,5205N6RSH2CS6 (Ref # 92045A)	92045-0014	1
BEARING-BALL,DG2152RDDSH2 (Ref # 92045B)	92045-0048	1
BEARING-NEEDLE (Ref # 92046)	92046-1291	1
RACE,30X38X15 (Ref # 92048)	92048-1053	1
BUSHING,GEAR,6TH IN (Ref # 92139)	92139-0036	1
BUSHING,GEAR,5TH IN&2ND OUT (Ref # 92139A)	92139-0037	2
BUSHING,GEAR,LOW OUT (Ref # 92139B)	92139-0038	1
BUSHING,GEAR,3RD&4TH OUT (Ref # 92139C)	92139-0066	2
COLLAR (Ref # 92152)	92152-0153	1
WASHER,28.3X34.0X1.6 (Ref # 92200)	92200-0050	2

2007 Ninja® ZX™-10R PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
WASHER,28.1X34.0X1.2 (Ref # 92200A)	92200-0051	2
WASHER (Ref # 92200B)	92200-0138	2
WASHER (Ref # 92200C)	92200-1065	1