


2006 Ninja® ZX™-10R PARTS DIAGRAM

Front Wheel



2006 Ninja® ZX™-10R PARTS LIST

Front Wheel

ITEM NAME	PART NUMBER	QUANTITY
BEARING-BALL,#6005UU (Ref # 601)	601B6005UU	2
AXLE,FR (Ref # 41068)	41068-0041	1
WHEEL-ASSY,FR,M.M.GOLD (Ref # 41073B)	41073-0084-11A	1
SEAL-OIL,BJN 32 47 5 (Ref # 92049)	92049-1377	2
COLLAR,FR HUB,L=115 (Ref # 92152)	92152-0242	1
COLLAR,FR AXLE,L=13 (Ref # 92152A)	92152-0289	2
NUT,24MM (Ref # 92210)	92210-0291	1