


# 1998 Ninja® ZX™-11 PARTS DIAGRAM

## Fuel Pump



## 1998 Ninja® ZX™-11 PARTS LIST

### Fuel Pump

ITEM NAME	PART NUMBER	QUANTITY
HOLDER (Ref # 13091)	13091-1512	1
RELAY-ASSY (Ref # 27002)	27002-1065	1
FILTER-FUEL (Ref # 49019)	49019-1055	1
PUMP-FUEL (Ref # 49040)	49040-1061	1
CLAMP (Ref # 92037)	92037-1181	3
DAMPER,FUEL FILTER (Ref # 92075)	92075-1853	1
SPRING,TUBE (Ref # 92144)	92144-1821	1
CLAMP (Ref # 92170)	92170-1491	2
TUBE (Ref # 92190)	92190-1153	1
TUBE,FUEL TAP-FUEL FILTER (Ref # 92190A)	92190-1394	1