


2002 Ninja® ZX™-12R PARTS DIAGRAM

Frame Fittings



2002 Ninja® ZX™-12R PARTS LIST

Frame Fittings

| ITEM NAME | PART NUMBER | QUANTITY |
|---|---------------|----------|
| BOLT-FLANGED,6X25 (Ref # 130) | 130J0625 | 3 |
| BOLT-FLANGED-SMALL (Ref # 132) | 132J0616 | 6 |
| PIN-COTTER,4.0X25 (Ref # 550) | 550D4025 | 1 |
| CAP,AXLE NUT (Ref # 11012) | 11012-1592 | 1 |
| BRACKET,TOOL CASE (Ref # 11051) | 11051-1377 | 1 |
| COVER,FUSE (Ref # 14091) | 14091-1238 | 1 |
| COVER,BATTERY (Ref # 14091A) | 14091-1288 | 1 |
| CASE-COMP-BATTERY (Ref # 31009) | 31009-1056 | 1 |
| BRACKET-SHOCKABSORBER (Ref # 32037A) | 32037-1800 | 1 |
| CASE-TOOL (Ref # 32098) | 32098-1131 | 1 |
| STAY,FR,LH (Ref # 35063D) | 35063-1062 | 1 |
| STAY,RR,LH (Ref # 35063E) | 35063-1064 | 1 |
| STAY,RR,RH (Ref # 35063F) | 35063-1065 | 1 |
| STAY,FR,RH (Ref # 35063G) | 35063-1236 | 1 |
| COVER-SIDE,FRAME,RH,F.S.BLACK (Ref # 36001) | 36001-1670-8F | 1 |
| PAD (Ref # 39156) | 39156-1649 | 1 |
| PAD (Ref # 39156A) | 39156-1650 | 2 |
| GUARD,FRONT STEP,LH (Ref # 55020) | 55020-1696 | 1 |
| GUARD,FRONT STEP,RH (Ref # 55020A) | 55020-1697 | 1 |
| SCREW,5X16 (Ref # 92009) | 92009-1909 | 1 |
| NUT (Ref # 92015) | 92015-1700 | 2 |
| NUT,FLANGED,16MM (Ref # 92015A) | 92015-1881 | 1 |
| WASHER,7X16X1.2 (Ref # 92022) | 92022-1344 | 1 |
| SPACER,SET (Ref # 92026) | 92026-1586 | 1 |
| BAND,L=150 (Ref # 92072) | 92072-1203 | 1 |
| BAND,TOOL (Ref # 92072A) | 92072-1349 | 1 |
| BAND,L=290 (Ref # 92072B) | 92072-1377 | 1 |
| DAMPER,RUBBER (Ref # 92075) | 92075-261 | 2 |
| WIRE,L=150 (Ref # 92086) | 92086-1075 | 2 |

2002 Ninja® ZX™ -12R PARTS LIST

Frame Fittings

| ITEM NAME | PART NUMBER | QUANTITY |
|----------------------------------|-------------|----------|
| BOLT,SOCKET,8X20 (Ref # 92150) | 92150-1839 | 4 |
| BOLT,6MM (Ref # 92151) | 92151-1334 | 2 |
| BOLT,SOCKET,10X30 (Ref # 92151A) | 92151-1372 | 4 |
| BOLT,SOCKET,6X21 (Ref # 92151B) | 92151-1880 | 2 |