


# 2006 Ninja® ZX™-12R (European) PARTS DIAGRAM

Air Cleaner



## 2006 Ninja® ZX™-12R (European) PARTS LIST

### Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,6X35 (Ref # 130)	130L0635	4
ELEMENT-AIR FILTER (Ref # 11013)	11013-0005	2
CAP,BREATHER (Ref # 11065)	11065-1088	1
CAP,FRAME,RH (Ref # 11065A)	11065-1129	1
CAP,FRAME,LH (Ref # 11065B)	11065-1130	1
BREATHER (Ref # 14069)	14069-1051	1
VALVE,AIR CUT (Ref # 16126)	16126-1437	1
FITTING (Ref # 92005)	92005-1309	2
FITTING (Ref # 92005A)	92005-1365	1
NUT,6MM (Ref # 92015)	92015-1365	4
PLUG (Ref # 92066)	92066-1576	4
GROMMET,AIR FILTER (Ref # 92071)	92071-1042	1
SEAL (Ref # 92093)	92093-1507	2
BOLT,6X22 (Ref # 92151)	92151-1236	6
CLAMP (Ref # 92170)	92170-1060	1
CLAMP (Ref # 92170A)	92170-1529	3
CLAMP (Ref # 92171)	92171-1277	1
TUBE,14X20X111 (Ref # 92191)	92191-1215	1
TUBE,ENGINE-CLEANER (Ref # 92191A)	92191-1352	1
TUBE,AIR SWITCH-CLEANER (Ref # 92191B)	92191-1353	1
TUBE,7X12X460 (Ref # 92191C)	92191-1517	1
TUBE,VALVE-ASWV LH (Ref # 92192)	92192-0090	1
TUBE,VALVE-ASWV RH (Ref # 92192A)	92192-0091	1
TUBE,ASWV-FITTING (Ref # 92192B)	92192-0092	1
NUT (Ref # 92210)	92210-1183	2