


1988 NINJA® 600R PARTS DIAGRAM

Valve(s)

E1210-0037



1988 NINJA® 600R PARTS LIST

Valve(s)

ITEM NAME	PART NUMBER	QUANTITY
VALVE-INTAKE (Ref # 12004)	12004-1075	8
VALVE-EXHAUST (Ref # 12005)	12005-1062	8
RETAINER-VALVE SPRING (Ref # 12009)	12009-1060	16
COLLET (Ref # 12011)	12011-1051	32
ARM-ROCKER (Ref # 12016)	12016-1062	8
SHAFT-ROCKER (Ref # 12020)	12020-1058	4
SEAT-SPRING,12.1X16.2X0.5 (Ref # 16007)	16007-1143	16
SEAT-SPRING,17.5X23.8X0.5 (Ref # 16007A)	16007-1144	16
SPRING-ENGINE VALVE,OUTER (Ref # 49078)	49078-1060	16
SPRING-ENGINE VALVE,INNER (Ref # 49078A)	49078-1061	16
SCREW,VALVE ADJUST (Ref # 92009)	92009-1109	16
NUT,5MM (Ref # 92015)	92015-1529	16
SEAL-OIL,VSB58.558 (Ref # 92049)	92049-1218	16
PLUG,14X11.5 (Ref # 92066)	92066-1192	4
SPRING,ROCKER ARM (Ref # 92081)	92081-1636	8
PIN-DOWEL (Ref # 551)	551A0540	4
O RING,15MM (Ref # 670)	670B2015	4