


# 1997 Ninja® 600R PARTS DIAGRAM

Rear Wheel/Chain



# 1997 Ninja® 600R PARTS LIST

## Rear Wheel/Chain

ITEM NAME	PART NUMBER	QUANTITY
AXLE,RR (Ref # 41068)	41068-1232	1
WHEEL-ASSY,RR,BLUE VIOLET (Ref # 41073)	41073-1576-5G	1
COUPLING-ASSY,RR HUB (Ref # 42033)	42033-1114	1
SLEEVE,RR HUB,L=26 (Ref # 42036)	42036-1149	1
SPROCKET-HUB,39T (Ref # 42041)	42041-1287	1
STUD,10X24 (Ref # 92004)	92004-1146	6
NUT,10MM (Ref # 92015)	92015-1720	6
NUT,CASTLE,16MM (Ref # 92015A)	92015-1947	1
COLLAR,RR AXLE,L=20 (Ref # 92027)	92027-1874	1
COLLAR,RR AXLE,L=28 (Ref # 92027A)	92027-1875	1
COLLAR,L=106 (Ref # 92027B)	92027-1876	1
RING-SNAP,47MM (Ref # 92033)	92033-1042	1
RING-SNAP,52MM (Ref # 92033A)	92033-1043	1
SEAL-OIL,BJN28475 (Ref # 92049)	92049-1056	1
SEAL-OIL,TWC35527 (Ref # 92052)	92052-006	1
CHAIN,DRIVE,EK50MV-OX102L (Ref # 92057)	92057-1232	1
DAMPER,SHOCK,RR HUB (Ref # 92075)	92075-1687	1
PIN-COTTER,4.0X35 (Ref # 550)	550D4035	1
BEARING-BALL,#6205G (Ref # 601)	601B6205G	1
BEARING-BALL,#6303UUC3 (Ref # 601A)	601B6303UU	2