


1992 Ninja® ZX™ -6 PARTS DIAGRAM

Air Filter

E1130



1992 Ninja® ZX™ -6 PARTS LIST

Air Filter

ITEM NAME	PART NUMBER	QUANTITY
CASE-AIR FILTER,LWR (Ref # 11011)	11011-1328	1
CASE-AIR FILTER,UPP (Ref # 11011A)	11011-1373	1
CASE-AIR FILTER,UPP (Ref # 11011B)	11011-1376	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-1189	1
HOLDER,AIR FILTER (Ref # 13091)	13091-1657	1
HOLDER,ELEMENT (Ref # 13091A)	13091-1658	1
HOLDER (Ref # 13091B)	13091-1672	1
DUCT,AIR INTAKE (Ref # 14073)	14073-1424	1
DUCT,CARBURETOR (Ref # 14073A)	14073-1442	4
VALVE,AIR SWITCH (Ref # 16126)	16126-1144	1
TANK-RESONATOR (Ref # 16181)	16181-1058	1
PAD (Ref # 39156)	39156-1213	1
FITTING,TUBE,T-TYPE (Ref # 92005)	92005-1017	1
SCREW-PAN-WSP-CROS,6X16 (Ref # 92009)	92009-1283	2
SCREW,6X35 (Ref # 92009A)	92009-1589	2
SCREW,6X144 (Ref # 92009B)	92009-1622	2
CLAMP,TUBE (Ref # 92037)	92037-1076	1
CLAMP (Ref # 92037A)	92037-1712	4
CLAMP (Ref # 92037A)	92037-1712	2
CLAMP,TUBE (Ref # 92037B)	92037-213	4
CLAMP,TUBE (Ref # 92037B)	92037-213	2
RING-O,67.7X3.1 (Ref # 92055)	92055-1434	4
TUBE,4X9X80 (Ref # 92059)	92059-1365	2
PLUG,DRAIN (Ref # 92066)	92066-1211	1
GROMMET,AIR FILTER (Ref # 92071)	92071-1028	1
GROMMET,AIR FILTER (Ref # 92071A)	92071-1114	1
SEAL,AIR FILTER CASE (Ref # 92093)	92093-1301	1
SEAL,AIR FILTER HOLDER (Ref # 92093A)	92093-1302	1
SEAL,AIR DUCT (Ref # 92093B)	92093-1303	1

1992 Ninja® ZX™-6 PARTS LIST

Air Filter

ITEM NAME	PART NUMBER	QUANTITY
TUBE,BREATHER (Ref # 92190)	92190-1088	1
TUBE,7X10X480 (Ref # 92190A)	92190-1089	1
TUBE,VALVE-AIR FILTER (Ref # 92190B)	92190-1090	1
TUBE,4X9X220 (Ref # 92190C)	92190-1091	1
TUBE,AIR SWITCH VALVE (Ref # 92190D)	92190-1168	2
BOLT-FLANGED (Ref # 130)	130G0516	8