


# 1998 Ninja® ZX™-6R PARTS DIAGRAM

Ignition System

E1830



# 1998 Ninja® ZX™-6R PARTS LIST

## Ignition System

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED (Ref # 130)	130G0512	2
BOLT-FLANGED (Ref # 130A)	130J0620	2
BOLT-FLANGED (Ref # 130B)	130R0650	1
BOLT-FLANGED (Ref # 130C)	130R0675	2
ROTOR (Ref # 21007)	21007-1331	1
COIL-IGNITION,#1&#4 (Ref # 21121)	21121-1277	1
COIL-IGNITION,#2&#3 (Ref # 21121A)	21121-1280	1
CAP-ASSY-PLUG (Ref # 21160)	21160-1088	4
COIL-PULSING (Ref # 59026)	59026-1129	1
NUT (Ref # 92015)	92015-1692	3
NUT (Ref # 92015A)	92015-1700	2
WASHER,6.5X16X2 (Ref # 92022)	92022-1342	1
COLLAR,6.3X10X14 (Ref # 92027)	92027-1453	1
COLLAR,L=21 (Ref # 92027A)	92027-195	2
PLUG-SPARK,CR9E(NGK) (Ref # 92070)	92070-1143	4
BOLT,8X23 (Ref # 92151)	92151-1308	1
COLLAR (Ref # 92152)	92152-1094	1
IGNITER (Ref # 21119)	21119-1513	1
IGNITER (Ref # 21119A)	21119-1514	1