


# 2001 Ninja® ZX™-6R PARTS DIAGRAM

Front Wheel

F2230



## 2001 Ninja® ZX™-6R PARTS LIST

### Front Wheel

ITEM NAME	PART NUMBER	QUANTITY
BEARING-BALL,#6005UU (Ref # 601)	601B6005UU	2
AXLE,FR (Ref # 41068)	41068-1426	1
WHEEL-ASSY,FR,L.GREEN (Ref # 41073)	41073-1633-CJ	1
WHEEL-ASSY,FR,M.L.BLUE (Ref # 41073B)	41073-1633-E7	1
WHEEL-ASSY,FR,YELLOW (Ref # 41073E)	41073-1633-9I	1
RING-SNAP,47MM (Ref # 92033)	92033-1042	1
SEAL-OIL,BJN 32 47 5 (Ref # 92049)	92049-1377	2
COLLAR,FR AXLE,LH,L=44.5 (Ref # 92143)	92143-1478	1
COLLAR,FR HUB,L=98 (Ref # 92152)	92152-1079	1
COLLAR,FR AXLE,L=21.5 (Ref # 92152A)	92152-1251	2