


# 2006 Ninja® ZX™-6RR PARTS DIAGRAM

## Chassis Electrical Equipment



## 2006 Ninja® ZX™-6RR PARTS LIST

### Chassis Electrical Equipment

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,6X10 (Ref # 130)	130V0610	3
BRACKET,RADIATOR (Ref # 11053)	11053-1228	1
RECTIFIER (Ref # 21061)	21061-0001	1
FUSE,15A (Ref # 26006)	26006-0001	3
FUSE,10A (Ref # 26006A)	26006-1078	6
WIRE-LEAD (Ref # 26011)	26011-0037	1
WIRE-LEAD,BATTERY(-) (Ref # 26011A)	26011-0056	1
WIRE-LEAD,BATTERY(+) (Ref # 26011B)	26011-0070	1
BATTERY,YTX9-BS,12V 8AH (Ref # 26012)	26012-1326	1
HARNESS,MAIN (Ref # 26031)	26031-0377	1
RELAY-ASSY,SIGNAL LAMP (Ref # 27002)	27002-0006	1
RELAY-ASSY (Ref # 27002A)	27002-0007	1
HORN (Ref # 27003)	27003-0030	1
LABEL,FUSE BOX (Ref # 56030)	56030-0091	1
LABEL,FUSE BOX (Ref # 56030A)	56030-0092	1
CLAMP,L=60 (Ref # 92037)	92037-1069	5
CLAMP,HOSE (Ref # 92037A)	92037-1827	1
BAND,L=202 (Ref # 92072)	92072-1195	2
BAND (Ref # 92072A)	92072-1414	1
BOLT,SOCKET,6X10 (Ref # 92153)	92153-0410	1
DAMPER,RELAY BOX (Ref # 92161)	92161-0203	1
DAMPER,SIGNAL RELAY (Ref # 92161A)	92161-0283	1
CLAMP (Ref # 92171)	92171-0462	1
CLAMP,HARNESS (Ref # 92171A)	92171-0465	2