


# 2006 Ninja® ZX™-6R PARTS DIAGRAM

Air Cleaner

E1130



## 2006 Ninja® ZX™-6R PARTS LIST

### Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,6X30 (Ref # 130)	130L0630	1
FILTER-ASSY-AIR (Ref # 11010)	11010-0061	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-0010	1
GASKET (Ref # 11061)	11061-0127	2
CAP,AIR FILTER CASE (Ref # 11065)	11065-0082	1
RECEIVER-OIL (Ref # 13045)	13045-1057	1
DUCT (Ref # 14073)	14073-0077	2
DUCT (Ref # 14073A)	14073-0081	2
VALVE,AIR SWITCH (Ref # 16126)	16126-1433	1
COLLAR,L=13.1 (Ref # 92027)	92027-251	1
CLAMP,TUBE (Ref # 92037)	92037-010	1
CLAMP (Ref # 92037A)	92037-1593	1
CLAMP (Ref # 92037B)	92037-1712	1
TUBE,6X9X360 (Ref # 92059)	92059-103	1
DAMPER (Ref # 92160)	92160-1162	1
CLAMP (Ref # 92170)	92170-1017	1
CLAMP (Ref # 92170A)	92170-1060	2
CLAMP,FUNNEL TIGHTEN (Ref # 92171)	92171-0436	4
SCREW,5X16 (Ref # 92172)	92172-0177	6
TUBE,10X16X29 (Ref # 92192)	92192-0009	2
TUBE,BLOW-BY (Ref # 92192A)	92192-0153	1
FITTING (Ref # 92005)	92005-1402	1
TUBE,FITTING-AIR SWITCH (Ref # 92191)	92191-1813	1
TUBE,A/C-ASV (Ref # 92192B)	92192-0154	1
TUBE,FITTING-A/C (Ref # 92192C)	92192-0168	1