


1988 NINJA® 750R PARTS DIAGRAM

Front Wheel

F2230-0147



1988 NINJA® 750R PARTS LIST

Front Wheel

ITEM NAME	PART NUMBER	QUANTITY
BEARING-BALL,#6302UG (Ref # 601)	601B6302UG	2
GEAR-METER SCREW,24T (Ref # 41060)	41060-1025	1
GEAR-METER SCREW,9T (Ref # 41060A)	41060-1035	1
RECEIVER-SPEEDOMETER (Ref # 41064)	41064-1006	1
AXLE,FR (Ref # 41068)	41068-1233	1
WHEEL-ASSY,FR,SILVER NO.1 (Ref # 41073C)	41073-1344-V5	1
CASE-ASSY-METER GEAR (Ref # 41078)	41078-1057	1
WASHER,5.1X9X0.4 (Ref # 92022)	41063-001	1
WASHER,5.1X10X1 (Ref # 92022A)	92022-1062	1
COLLAR,L=34 (Ref # 92027)	92027-1118	1
COLLAR,FR AXLE,L=36.5 (Ref # 92027A)	92027-1726	1
RING-SNAP,42MM (Ref # 92033)	92033-1041	2
PIN,SPRING (Ref # 92043)	41082-001	1
SEAL-OIL,BJN30427-C3 (Ref # 92049)	92049-1057	1
SEAL-OIL,BJN22425 (Ref # 92049A)	92049-1058	1
BUSHING-METER GEAR (Ref # 92087)	92087-1002	1
COLLAR,15.2X22X67 (Ref # 92143)	92143-1033	1