


# 1996 Ninja® ZX™-7RR PARTS DIAGRAM

Generator



# 1996 Ninja® ZX™-7RR PARTS LIST

## Generator

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED (Ref # 130)	130Z0870	2
HOLDER,COVER (Ref # 13091)	13091-1327	1
HOLDER,BEARING (Ref # 13091A)	13091-1328	1
HOLDER,BRUSH (Ref # 13091B)	13091-1465	1
RECTIFIER (Ref # 13091C)	13091-1466	1
HOLDER,BEARING (Ref # 13091D)	13091-1748	1
HOUSING,GENERATOR (Ref # 13227)	13227-1106	1
PLATE-POSITION (Ref # 14014)	14014-1105	1
COVER,RECTIFIER (Ref # 14090)	14090-1113	1
COVER,GENERATOR (Ref # 14090A)	14090-1114	1
GENERATOR (Ref # 21001)	21001-1115	1
ROTOR,GENERATOR (Ref # 21007)	21007-1229	1
BRUSH,CARBON (Ref # 21039)	21039-1052	2
REGULATOR-VOLTAGE (Ref # 21066)	21066-1076	1
WIRE-LEAD,GENERATOR (Ref # 26011)	26011-1497	1
FRAME,GENERATOR (Ref # 31011)	31011-1067	1
COUPLING (Ref # 42034)	42034-1056	1
BOLT,8X63 (Ref # 92002)	92002-1215	1
SCREW,5X17.5 (Ref # 92002A)	92002-1380	3
BOLT,6X105 (Ref # 92002B)	92002-1585	2
STUD (Ref # 92004)	92004-1196	2
SCREW (Ref # 92009)	92009-1645	4
SCREW (Ref # 92009A)	92009-1646	3
NUT,10MM (Ref # 92015)	92015-1850	1
NUT (Ref # 92015A)	92015-1851	2
BEARING-BALL,#6003 (Ref # 92045)	92045-1248	1
BEARING-BALL,#6002NC (Ref # 92045A)	92045-1249	1
SEAL-OIL (Ref # 92049)	92049-1390	1
RING-O (Ref # 92055)	92055-1496	1

# 1996 Ninja® ZX™-7RR PARTS LIST

Generator

ITEM NAME	PART NUMBER	QUANTITY
SPRING,BRUSH (Ref # 92081)	92081-1759	2