


1998 Ninja® ZX™-7R PARTS DIAGRAM

Transmission



1998 Ninja® ZX™-7R PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
CIRCLIP (Ref # 480)	480J2900	1
BALL-STEEL,5/32" (Ref # 600)	600A0500	3
SHAFT-TRANSMISSION INPUT (Ref # 13127)	13127-1244	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-1208	1
SPROCKET-OUTPUT,16T (Ref # 13144)	13144-1256	1
GEAR,INPUT TOP,29T (Ref # 13260)	13260-1401	1
GEAR,INPUT 2ND,18T (Ref # 13260A)	13260-1526	1
GEAR,OUTPUT 5TH,33T (Ref # 13260B)	13260-1528	1
GEAR,OUTPUT TOP,32T (Ref # 13260C)	13260-1529	1
GEAR,OUTPUT LOW,40T (Ref # 13260D)	13260-1538	1
GEAR,OUTPUT 2ND,36T (Ref # 13260E)	13260-1539	1
GEAR,INPUT 3RD&4TH,21T&23T (Ref # 13260F)	13260-1608	1
GEAR,INPUT 5TH,27T (Ref # 13260G)	13260-1609	1
GEAR,OUTPUT 3RD,34T (Ref # 13260H)	13260-1612	1
GEAR,OUTPUT 4TH,32T (Ref # 13260I)	13260-1613	1
NUT,20MM (Ref # 92015)	92015-1963	1
SPACER,22X35.5X2.1 (Ref # 92026)	92026-1224	2
BUSHING,INPUT 5TH GEAR (Ref # 92028)	92028-1449	1
BUSHING,OUTPUT GEAR,2ND (Ref # 92028A)	92028-1707	1
BUSHING,INPUT TOP GEAR (Ref # 92028B)	92028-1752	1
BUSHING,OUTPUT,3RD&4TH (Ref # 92028C)	92028-1753	1
RING-SNAP,20X25.5X1.2 (Ref # 92033)	92033-025	1
RING-SNAP,T=1.2 (Ref # 92033A)	92033-1037	2
BEARING-BALL,6305N2SH2 (Ref # 92045)	92045-1224	1
BEARING-BALL,5305X (Ref # 92045A)	92045-1323	1
BEARING-NEEDLE,FWF-223014 (Ref # 92046)	92046-031	2
RACE,INPUT SHAFT (Ref # 92048)	92048-1066	1
RACE,0RZ30X38X17PX1 (Ref # 92048A)	92048-1067	1
COLLAR,ENGINE SPROCKET (Ref # 92143)	92143-1788	1

1998 Ninja® ZX™-7R PARTS LIST

Transmission

ITEM NAME	PART NUMBER	QUANTITY
WASHER (Ref # 92200)	92200-1065	1
WASHER,T=1.5 (Ref # 92200A)	92200-1240	2
WASHER,TOOTHED,28X30X2 (Ref # 92200B)	92200-1277	1
WASHER,29.9X40X1.5 (Ref # 92200C)	92200-1278	1