


# 1996 Ninja® ZX™-9R PARTS DIAGRAM

## Transmission



# 1996 Ninja® ZX™-9R PARTS LIST

## Transmission

ITEM NAME	PART NUMBER	QUANTITY
SHAFT-TRANSMISSION INPUT,14T (Ref # 13127)	13127-1205	1
SHAFT-TRANSMISSION OUTPUT (Ref # 13128)	13128-1181	1
SPROCKET-OUTPUT,17T(#530) (Ref # 13144)	13144-1009	1
SPROCKET-OUTPUT,15T(#530) (Ref # 13144A)	13144-1117	1
SPROCKET-OUTPUT,16T (Ref # 13144C)	13144-1275	1
GEAR,OUTPUT LOW,40T (Ref # 13260)	13260-1165	1
GEAR,INPUT 5TH,27T (Ref # 13260B)	13260-1400	1
GEAR,INPUT TOP,29T (Ref # 13260C)	13260-1401	1
GEAR,INPUT 3RD&4TH,20T&23T (Ref # 13260D)	13260-1410	1
GEAR,INPUT 2ND,18T (Ref # 13260G)	13260-1422	1
GEAR,OUTPUT 2ND,37T (Ref # 13260J)	13260-1490	1
GEAR,OUTPUT 3RD,33T (Ref # 13260K)	13260-1491	1
GEAR,OUTPUT 4TH,32T (Ref # 13260L)	13260-1492	1
GEAR,OUTPUT 5TH,33T (Ref # 13260M)	13260-1493	1
GEAR,OUTPUT TOP,32T (Ref # 13260N)	13260-1494	1
NUT,20MM (Ref # 92015)	92015-1963	1
WASHER,TOOTHED,26X35.5X1.5 (Ref # 92024)	92024-042	2
WASHER,TOOTHED,30.3X40X1.5 (Ref # 92024A)	92024-043	3
SPACER,22X35.5X2.1 (Ref # 92026)	92026-1224	2
BUSHING,INPUT TOP GEAR (Ref # 92028)	92028-1255	1
BUSHING,OUTPUT 3RD&4TH (Ref # 92028A)	92028-1363	1
BUSHING (Ref # 92028B)	92028-1448	1
BUSHING,INPUT 5TH GEAR (Ref # 92028C)	92028-1449	1
BUSHING,OUTPUT 2ND (Ref # 92028D)	92028-1450	1
RING-SNAP,20X25.5X1.2 (Ref # 92033)	92033-025	1
RING-SNAP,T=1.2 (Ref # 92033A)	92033-1037	2
RING-SNAP (Ref # 92036)	92036-005	1
BEARING-BALL,6305N2SH2 (Ref # 92045)	92045-1224	2
BEARING-NEEDLE,FWF-223014 (Ref # 92046)	92046-031	2

# 1996 Ninja® ZX™-9R PARTS LIST

## Transmission

ITEM NAME	PART NUMBER	QUANTITY
RACE,INPUT SHAFT (Ref # 92048)	92048-1066	1
RACE,0RZ30X38X17PX1 (Ref # 92048A)	92048-1067	1
COLLAR,ENGINE SPROCKET (Ref # 92143)	92143-1757	1
CIRCLIP (Ref # 480)	480J2900	3
BALL-STEEL,5/32" (Ref # 600)	600A0500	3
WASHER (Ref # 92200)	92200-1065	1