


# 1997 Ninja® ZX™-9R PARTS DIAGRAM

## Air Cleaner



# 1997 Ninja® ZX™ -9R PARTS LIST

## Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
FILTER-ASSY-AIR (Ref # 11010)	11010-1511	1
CAP (Ref # 11012)	11012-1899	1
ELEMENT-AIR FILTER (Ref # 11013)	11013-1232	1
GUIDE,AIR FILTER (Ref # 13070)	13070-1230	2
HOLDER (Ref # 13091)	13091-1864	2
HOLDER,AIR FILTER (Ref # 13091A)	13091-1865	1
SCREEN,AIR FILTER (Ref # 14037)	14037-1182	1
SCREEN,LH (Ref # 14037A)	14037-1185	1
SCREEN,RH (Ref # 14037B)	14037-1186	1
BREATHER (Ref # 14069)	14069-1051	1
DUCT,AIR FILTER (Ref # 14073)	14073-1575	4
DUCT,AIR INTAKE,FR,LH (Ref # 14073A)	14073-1589	1
DUCT,AIR INTAKE,FR,RH (Ref # 14073B)	14073-1590	1
DUCT,AIR INTAKE,RR,LH (Ref # 14073C)	14073-1591	1
DUCT,AIR INTAKE,RR,RH (Ref # 14073D)	14073-1592	1
DUCT,AIR INTAKE,COWL,LH (Ref # 14073E)	14073-1595	1
DUCT,AIR INTAKE,COWL,RH (Ref # 14073F)	14073-1596	1
VALVE,AIR SWITCH (Ref # 16126)	16126-1104	1
VALVE,CANISTER (Ref # 16126A)	16126-1272	1
TANK-RESONATOR,LH (Ref # 16181)	16181-1074	1
TANK-RESONATOR,RH (Ref # 16181A)	16181-1075	1
PIPE (Ref # 32151)	32151-1572	2
PIPE (Ref # 32151A)	32151-1598	1
SILENCER-INTAKE (Ref # 39162)	39162-1003	1
FILTER-AIR (Ref # 49064)	49064-1055	1
FILTER-AIR (Ref # 49064)	49064-1055	2
VALVE-ASSY (Ref # 49116)	49116-1116	1
FITTING,TUBE,T-TYPE (Ref # 92005)	92005-1017	1
FITTING,Y-TIPE (Ref # 92005A)	92005-1250	1

# 1997 Ninja® ZX™-9R PARTS LIST

## Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
FITTING,T-TYPE (Ref # 92005B)	92005-1252	1
SCREW,6X16 (Ref # 92009)	92009-1621	6
NUT,WELL,5MM (Ref # 92015)	92015-1640	4
NUT (Ref # 92015A)	92015-1700	4
NUT,CLIP,6MM (Ref # 92015B)	92015-1904	2
CLAMP,TUBE (Ref # 92037)	92037-1461	2
CLAMP,TUBE (Ref # 92037)	92037-1461	3
CLAMP,TUBE (Ref # 92037A)	92037-147	13
CLAMP,HOSE (Ref # 92037B)	92037-1603	3
CLAMP (Ref # 92037C)	92037-1730	1
RING-O,67.7X3.1 (Ref # 92055)	92055-1434	4
RING-O (Ref # 92055A)	92055-1524	1
TUBE,FUEL,4X9X140 (Ref # 92059)	92059-1230	2
TUBE,4X9X500,WHITE (Ref # 92059A)	92059-1533	1
PLUG,DRAIN (Ref # 92066)	92066-1211	5
PLUG (Ref # 92066A)	92066-1389	4
GROMMET,AIR FILTER (Ref # 92071)	92071-1013	2
SEAL (Ref # 92093)	92093-1364	1
SEAL,HOLDER (Ref # 92093A)	92093-1365	1
SEAL (Ref # 92093B)	92093-1366	2
BOLT,5X16 (Ref # 92150)	92150-1363	4
BOLT (Ref # 92150A)	92150-1767	4
DAMPER (Ref # 92160)	92160-1489	1
CLAMP (Ref # 92170)	92170-1060	2
CLAMP (Ref # 92170A)	92170-1118	3
CLAMP (Ref # 92170B)	92170-1307	2
CLAMP,BRAKE HOSE (Ref # 92170C)	92170-1434	2
CLAMP (Ref # 92170D)	92170-1486	4
CLAMP (Ref # 92170D)	92170-1486	7

# 1997 Ninja® ZX™ -9R PARTS LIST

## Air Cleaner

ITEM NAME	PART NUMBER	QUANTITY
TUBE,HEAD-AIR SWITCH,LH (Ref # 92190)	92190-1197	1
TUBE,HEAD-AIR SWITCH,RH (Ref # 92190A)	92190-1198	1
TUBE,BREATHER (Ref # 92190B)	92190-1482	1
TUBE (Ref # 92190C)	92190-1483	1
TUBE,AIR VENT,FR,LH (Ref # 92190D)	92190-1505	1
TUBE,AIR VENT,FR,RH (Ref # 92190E)	92190-1506	1
TUBE,VALVE-PIPE (Ref # 92190F)	92190-1507	1
TUBE,ACV-FITTING (Ref # 92190G)	92190-1512	1
TUBE,FITTING-AIR FILTER (Ref # 92190H)	92190-1513	1
BOLT-FLANGED (Ref # 130)	130H06105	2
BOLT-FLANGED,6X25 (Ref # 130A)	130H0625	5
BOLT-FLANGED (Ref # 130B)	130J0520	4
BOLT-FLANGED,6X30,BLACK (Ref # 130C)	130J0630	4
TUBE-RUBBER (Ref # 702)	702A07360	2
TUBE-RUBBER,7X10X400 (Ref # 702A)	702A07400	1
TUBE-RUBBER (Ref # 702B)	702A07515	2
TUBE,FITTING-FILTER (Ref # 92190I)	92190-1516	1
TUBE,FILTER-VALVE (Ref # 92190J)	92190-1517	1
TUBE,HEAD COVER-VALVE (Ref # 92190K)	92190-1543	1
TUBE (Ref # 92190L)	92190-1544	1
TUBE,DRAIN (Ref # 92190M)	92190-1549	1
TUBE,3WAY-AVT (Ref # 92190N)	92190-1558	1
TUBE,AIR VENT,FR,LH (Ref # 92190O)	92190-1561	1
TUBE,AIR VENT,FR,RH (Ref # 92190P)	92190-1562	1
TUBE (Ref # 92190Q)	92190-1564	1
TUBE,SILENCER-AIR FILTER (Ref # 92190R)	92190-1582	1