


1998 Ninja® ZX™-9R PARTS DIAGRAM

Air Duct

E1131



1998 Ninja® ZX™-9R PARTS LIST

Air Duct

ITEM NAME	PART NUMBER	QUANTITY
BRACKET,LH (Ref # 11050A)	11050-1513	1
BRACKET,RH (Ref # 11050B)	11050-1514	1
SCREEN,AIR DUCT (Ref # 14037)	14037-1246	2
DUCT,AIR LH,M.F.C.GRAY (Ref # 14073)	14073-1705-E4	1
DUCT,AIR FILTER (Ref # 14073A)	14073-1706	2
DUCT,AIR RH,M.F.C.GRAY (Ref # 14073B)	14073-1707-E4	1
TANK-RESONATOR (Ref # 16181)	16181-1089	1
TANK-RESONATOR (Ref # 16181A)	16181-1090	1
PIPE (Ref # 32152)	32152-1042	1
PIPE (Ref # 32152A)	32152-1568	2
FILTER-AIR (Ref # 49064)	49064-1061	1
SCREW,5X16,BLACK (Ref # 92009)	92009-1654	14
NUT,WELL,5MM (Ref # 92015)	92015-1757	14
WASHER,NYLON,5.3X11.5X1.5 (Ref # 92022)	92022-1521	10
CLAMP,AIR FILTER,ID=76,BLACK (Ref # 92037)	92037-129	4
CLAMP (Ref # 92037B)	92037-1654	2
CLAMP,SPEED,L=80.5 (Ref # 92037C)	92037-1903	1
GROMMET,AIR FILTER (Ref # 92071)	92071-1042	2
SEAL,AIR DUCT,LH (Ref # 92093)	92093-1454	1
SEAL,AIR DUCT,RH (Ref # 92093A)	92093-1455	1
SEAL,AIR FILTER DUCT (Ref # 92093B)	92093-1456	2
SEAL (Ref # 92093C)	92093-1470	2
CLAMP (Ref # 92170A)	92170-1486	2
CLAMP (Ref # 92170C)	92170-1909	3
SCREW-PAN-CROSS (Ref # 220)	220D0520	4
TUBE,LH (Ref # 92191A)	92191-1181	1
TUBE,RH (Ref # 92191B)	92191-1182	1
BRACKET (Ref # 11050)	11050-1509	1
VALVE (Ref # 16126)	16126-1346	1

1998 Ninja® ZX™-9R PARTS LIST

Air Duct

ITEM NAME	PART NUMBER	QUANTITY
CLAMP,TUBE (Ref # 92037A)	92037-1461	2
DAMPER,MUFFLER (Ref # 92075)	92075-1621	2
CLAMP (Ref # 92170)	92170-1118	1
CLAMP (Ref # 92170)	92170-1118	3
TUBE (Ref # 92191)	92191-1180	1
TUBE (Ref # 92191C)	92191-1190	1
TUBE (Ref # 92191D)	92191-1191	1
TUBE (Ref # 92191E)	92191-1192	1