


# 2008 Mule 3010 Trans4x4 PARTS DIAGRAM

Ignition Switch

F2770



## 2008 Mule 3010 Trans4x4 PARTS LIST

### Ignition Switch

| ITEM NAME                              | PART NUMBER | QUANTITY |
|--|-------------|----------|
| SWITCH-COMP,D.C.TERMINAL (Ref # 13151) | 13151-0003  | 1        |
| SWITCH-ASSY-IGNITION (Ref # 27005)     | 27005-1244  | 1        |
| KEY-LOCK,BLANK (Ref # 27008)           | 27008-1153  | 1        |
| KEY-LOCK,BLANK (Ref # 27008A)          | 27008-1157  | 1        |
| SWITCH,HEAD LAMP (Ref # 27010)         | 27010-1498  | 1        |
| BULB,12V 1.7W,T6.5 (Ref # 92069)       | 92069-1118  | 1        |
| NUT,IGNITION SWITCH (Ref # 92210)      | 92210-1264  | 1        |
| REFLECTOR-REFLEX,FR (Ref # 28012)      | 28012-1086  | 2        |