


2008 Prairie® 360 4X4 PARTS DIAGRAM

Ignition System

E1830



2008 Prairie® 360 4X4 PARTS LIST

Ignition System

ITEM NAME	PART NUMBER	QUANTITY
BOLT-FLANGED,5X16 (Ref # 130)	130BA0516	2
BOLT-FLANGED,6X25 (Ref # 130A)	130BB0625	2
BOLT-FLANGED-SMALL,6X16 (Ref # 132)	132BA0616	1
BOLT-FLANGED-SMALL,8X22 (Ref # 132A)	132BA0822	1
BOLT-FLANGED-SMALL,6X20 (Ref # 132B)	132BD0620	1
IGNITER (Ref # 21119)	21119-0060	1
COIL-IGNITION (Ref # 21121)	21121-1160	1
CAP-SPARK PLUG (Ref # 21130)	21130-1071	1
CONTROL UNIT-ELECTRONIC (Ref # 21175)	21175-0086	1
SENSOR,SPEED (Ref # 21176)	21176-1104	1
SENSOR,REVERSE (Ref # 21176A)	21176-1109	1
GUARD (Ref # 55020)	55020-0247	1
COIL-PULSING (Ref # 59026)	59026-1110	1
RING-O (Ref # 92055)	92055-1718	1
PLUG-SPARK,DPR8EA-9(NGK) (Ref # 92070)	92070-1065	1