


# 1983 LTD Belt PARTS DIAGRAM

CRANKCASE

E1411-0073



# 1983 LTD Belt PARTS LIST

## CRANKCASE

ITEM NAME	PART NUMBER	QUANTITY
GASKET (Ref # 11009)	16079-002	1
GASKET,DRIN PLUG (Ref # 11009A)	92065-097	1
CAP (Ref # 11012)	16078-002	1
SET-CRANKCASE (Ref # 14001)	14001-5129	1
PLATE,POSITIONING,CAM CHAIN (Ref # 14014)	14014-035	1
PLATE,POSITIONING,CHANGE DRUM (Ref # 14014A)	14014-037	1
PLATE,POSITIONING (Ref # 14014B)	14014-1004	1
BREATHER JOINT (Ref # 92005)	14067-006	1
BUSHING (Ref # 92028)	92028-132	1
CLAMP,HARNESS (Ref # 92037)	92037-1273	1
PIN,DOWEL,14MM (Ref # 92043)	92042-032	2
BEARING,BALL,#6306 (Ref # 92045)	92045-037	1
BEARING,BALL#6006 (Ref # 92045A)	92045-038	1
BEARING-NEEDLE (Ref # 92046)	92046-1184	1
BRG,NEEDLE,HMK1515B (Ref # 92046A)	92046-060	1
OIL SEAL,CHANGE SHAFT (Ref # 92049)	92050-082	1
SEAL-OIL,TC32457 (Ref # 92049A)	92049-1159	1
PLUG,OIL DRAIN,12X15 (Ref # 92066)	92066-1174	1
PLUG (Ref # 92066A)	92066-1282	2
PLUG (Ref # 92066B)	92066-1116	1
SCREW PAN HEAD 6X10 (Ref # 220)	220B0610	1
SCREW PAN HEAD 6X14 (Ref # 220A)	220B0614	4
SCREW PAN HEAD 6X30 (Ref # 220B)	220B0630	9
SCREW PAN HEAD 6X55 (Ref # 220C)	220B0655	3
SCREW PAN HEAD 6X75 (Ref # 220D)	220B0675	1
SCREW CNTSNK HD 6X16 (Ref # 221)	221B0616	3
BEARING BALL #6205 (Ref # 601)	601B6205	1