


# 1969 Bushmaster PARTS DIAGRAM

IGNITION/GENERATOR ('74-75)



# 1969 Bushmaster PARTS LIST

## IGNITION/GENERATOR ('74-'75)

ITEM NAME	PART NUMBER	QUANTITY
COIL IGNITION (Ref # 1)	21121-1048	1
WASHER SPRING 6MM (Ref # 2)	461F0600	2
NUT 6MM (Ref # 3)	311B0600	2
CAP, SPARK PLUG (Ref # 4)	21130-009	1
SPRING-SPARK PLUG CAP (Ref # 5)	92101-001	1
MAGNETO ASSY (Ref # 6)	21002-1055	1
FLYWHEEL (Ref # 6)	21050-017	1
MAGNETO ASSY (Ref # 7)	21002-1055	1
STATOR ASSY (Ref # 7)	21003-027	1
SCREW PAN HEAD 4X30 (Ref # 8)	220E0430	1
WASHER SPRING 4MM (Ref # 9)	461F0400	2
SCREW PAN HEAD 4X6 (Ref # 10)	220B0406	3
SCREW-PAN-CRSOSS,4X12 (Ref # 11)	220B0412	1
FELT OIL (Ref # 12)	21019-005	1
BREAKER ASSY CONTACT (Ref # 13)	21008-006	1
COIL PRIMARY (Ref # 14)	21049-006	1
COIL A,LIGHTING (Ref # 14)	21047-022	1
COIL LIGHTING A (Ref # 15)	21047-010	1
COIL A LIGHTING (Ref # 15)	21047-019	1
COIL LIGHTING B (Ref # 16)	21047-011	1
COIL,EXCITING (Ref # 16)	21049-1004	1
CONDENSER (Ref # 17)	21013-006	1
WIRING HARNESS,MAGNTO (Ref # 18)	21029-025	1
WIRING HARNESS,MAGNT (Ref # 18)	21029-031	1
GROMMET WIRING HARN (Ref # 19)	21017-002	1
PLATE-COIL,MAGNETO (Ref # 20)	21048-1002	1
CLAMP WIRING HARNESS (Ref # 21)	21037-002	1
SCREW CNTSNK HD 6X14 (Ref # 22)	221B0614	2
RECTIFIER (Ref # 23)	21061-015	1

# 1969 Bushmaster PARTS LIST

IGNITION/GENERATOR ('74-'75)

ITEM NAME	PART NUMBER	QUANTITY
BOLT HEX HEAD 5X10 (Ref # 24)	110B0510	1
WASHER SPRING 5MM (Ref # 25)	461F0500	1
NUT,5MM (Ref # 26)	311B0500	1
HOLDER,OIL FELT (Ref # 27)	21038-002	1